



USER'S MANUAL

SHOWLIGHT LED SPOT 180W ZOOM In Door



1-Maintenance

- 1.Please keep the light in dryness and avoiding use in wet place.**
- 2.Using intermittently can be extended the life.**
- 3.Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.**
- 4.Please do not wipe the crust using organic menstruum for avoid to damaged the product.**

2-Statement

The product has well capability and intact packing when leave factory,All of the user should comply with above warning item and manual ,any misuse cause of the damages are not included in our guarantee,and also can't be responsible for any malfunction & problem owing to ignore the manual. Please forgive that we will not be notice for technical change

3-Attention Item

- 1.For guarantee the life of product,please do not put it on the wet place and not use it the place over 40 degree.**
- 2.Please don't lay the product on the un-fixable or shakable place.**
- 3.Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.**
- 4.Power supply should not be changed over +&-10% while the light is using,it will be decreased the**

life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.

5. After power off, if it is need used again, please cool down over 20 minuter.

6. Please look round the manual for ensure the product can be used normally.

4-Product Introduction

- * Power Supply: AC90--275V, 50--60HZ
- * Power consumption: 324W
- * Fixing lamp: LED 18×18W RGBWA UV
- * DMX-Control-channels: 12 DMX Channels
- * Shuttle: Flash rate: 0--10HZ
- * Dimmer: 0-100% mechanic dimmer
- * Long Lifespan LEDs (more than 60,000 hours)

Display Control Instruction		
Display	Translate	Function
<i>A001-A512</i>	DMX Address	Channel address code, (001--512)
<i>AUD1-5002</i>	Function	Auto 10mode ; Sound contro 2 mode
<i>St00-St16</i>	Strobe	Strobe Speed
<i>SP01-SP16</i>	Speed	Function speed
<i>r000-r255</i>	Red	Red dimming
<i>G000-G255</i>	Green	Green dimming
<i>b000-b255</i>	Blue	Blue dimming
<i>U000-U255</i>	White	White dimming
<i>A000-A255</i>	Amber	Amber dimming
<i>P000-P255</i>	Violet	Violet dimming
<i>E000-E255</i>	Focusing	Focusing adjust

DMX 12 Channel Summary

Channel	Value	Features
CH1	0-255	Total light adjustment
CH2	0-255	Red Dimmer
CH3	0-255	Green Dimmer
CH4	0-255	Blue Dimmer
CH5	0-255	White Dimmer
CH6	0-255	Amber Dimmer
CH7	0-255	Violet Dimmer
CH8	0-255	Strobe
CH9	0-255	Focusing
CH10	0-255	Focusing Stop
CH11	0-239	Function
	240-255	Sound control
CH12	0-255	Program speed adjustment